



HANDLEBAR INSTALLATION

1. Make sure your bar and stem come with the same diameter at clamping area.
2. Check if there are any dirt or debris on the clamp area. Clean it if necessary.
3. Position the stem clamp according to the center mark of the handlebar.
Lightly tighten the clamping bolts so that you can easily adjust the handlebar position.
4. Rotate the handlebar to preferred position and make sure the handlebar is equal length on either side of the clamp.
5. Torque the clamping bolts according to the stem's specification.

HANDLEBAR CUTTING

- If you choose to cut the handlebar, make sure you don't cut past the last indicated mark on the handlebar.
- Cutting the carbon handlebar requires special care, please consult a professional bike mechanic before cutting.
- Do not use bar ends on cut carbon handlebars.